

Installing Canon PowerShot S80 Flash

Tools used in this guide

- Metal Spudger
- Phillips #00 Screwdriver
- Tweezers



Step 1 - disassembly Outer Casing

- Remove the knot on the wrist lanyard.
- Remove the battery and memory card.







- Remove all screws from sides of outer casing.
- Begin removing the screws on the bottom of the outer casing.
- Remove the rest of the screws from the outer casing.




• Gently pull the front cover off the camera.











- Open the "A/V Out Digital" cover slide, and remove the screw inside.
- Gently pull off the back casing.
- Remove the black "L" shaped piece of metal.



Step 5 - LCD Screen


- Remove the three screws that are holding the screen in place and free the screen from the underlying components.
- Be careful of the ribbon wire that is still attached on the left of the screen.








- With the spudger, gently lift the black flap that is holding the wide ribbon cable wire in place.
- Unplug the wide ribbon cable.
- Unplug the narrow ribbon cable to free the LCD screen from the camera body




Step 7 - Flash

- Remove the L-shaped corner trim containing the picture button.
- Carefully unplug the connection cable attached.





- Pull the selector wheel from the top corner of the camera.
- With a set of tweezers, carefully remove the ribbon cable connection.




Step 9

• Unscrew the zoom toggle switch and remove.




Step 10

☑ Unscrew the flash board.




Step 11

- With a metal spudger, gently pry up and remove the cable connection.
- With a metal spudger, gently lift up black tab to remove ribbon cable.



Step 12

• Lift the flash bulb unit from the camera.





• Lift the entire three-part flash assembly from the camera.